



COMPACT MAGWELL INSTALLATION INSTRUCTIONS



Always make sure your pistol is unloaded and clear before beginning product installation.

Samson Tech Support
Available M-F, 8-4:30p EST



Step 1

Orient the Compact Magwell with the finger groove toward the muzzle so that the clamp mechanism aligns with the pocket in the backstrap.



Step 2

Insert the locating pin at the front of the Compact Magwell into the magazine release spring notch in the pistol frame. Do not adjust the depth of the locating pin.



Step 3

With the locating pin fully engaged push the clamp mechanism into the backstrap pocket with enough force to close the gap between the frame and the Compact Magwell.



Step 4

Using provided 1/16" hex wrench tighten Compact Magwell clamp screw, turning the screw counter clockwise until the screw head is flush with the bottom of the Compact Magwell.

*After tightening, pull down on Compact Magwell to ensure there is no movement from pistol. If movement is observed, reverse Step 4 and repeat Steps 3 and 4.