

SAMSON SXS BARREL NUT

INSTALLATION INSTRUCTIONS

Always make sure your rifle is unloaded and clear before beginning installation of the Samson SXS Barrel Nut.

- 1. Remove existing handguard, gas tube and gas block if present.
- **2. Torque** Samson Barrel Nut to receiver with provided barrel nut wrench.
- **3. Reinstall** gas block and gas tube per manufacturer's instructions.
- **4. Mount** Handguard by sliding it over barrel, gas block, and gas tube assembly onto the barrel nut until handguard bottoms out on receiver face.
- **5. Tighten** the clamp screws on the handguard until clamp contacts barrel nut. Tighten bottom clamp screw until tight.

